CXP Compression Connector Buyer's Guide



-1 <i>//</i> "	Sunar	flavih	le Cable
			ic Gabic

Cables Supported: CommScope FSJ1-50A, FSJ1RK-50B, PTS1-50-P; RFS SCF14-50J, SCF14-50JFN; Hansen RF5014S, RF5014SZ; Eupen EC1-50-HF; Times SPP-250-LLPL, SPO-250; HUBER+SUHNER SUCOFEED 1/4 HFFR, SUCOFEED 1/4 HF.

Installation Instructions

SPO-250; HUBER+SUHNER SUCOFEED 1/4 HFFR, SUCOFEED 1/4 HF.				<u></u>
Interface Types	7-16 DIN	4.3-10	N	4.1-9.5
Male	CXP-DM-14S	CXP-4MT-14S	CXP-NM-14S	CXP-MDM-14S
Female	CXP-DF-14S	<u>CXP-4F-14S</u>	CXP-NF-14S	n/a
Right Angle	CXP-DRA-14S	CXP-4RT-14S	CXP-NRA-14S	CXP-MRA-14S

1/2" Superflexible Cable

Cables Supported: CommScope FSJ4, FSJ4RK, FSJ4RN-50; RFS SCF12; NK Draka RFF1200; Eupen EC4HF; Leoni Flexline 1/2"S; LS/Superior Essex HFSC 12D; Hansen RF5012S, RF5012SZ; Rosenbeger SL 1/2" S; HUBER+SUHNER SF 1/2 HF.

Installation Instructions

RF50125, RF501252; Rosenbeger SL 1/2 S; HUBER+SUHNER SF 1/2 HF.					
Interface Types	7-16 DIN	4.3-10	N	4.1-9.5	
Male	CXP-DM-12S	CXP-4MT-12S	CXP-NM-12S	CXP-MDM-12S	
Female	CXP-DF-12S	CXP-4F-12S	CXP-NF-12S	n/a	
Right Angle	CXP-DRA-12S	<u>CXP-4RT-12S</u>	CXP-NRA-12S	CXP-MRA-12S	

1/2" Annular Cable

Cables Supported: CommScope LDF4, LDF4RK, LDF4 RN; RFS LCF12; NK Draka RFA1200; Eupen EC4; Leoni Flexline 1/2"R; Hansen RF5012, RF5012Z; Rosenberger SL 1/2" R; LS/Super Essex HFC 12D, HFAC 12D.

Installation Instructions

Interface Types	7-16 DIN	4.3-10	N	4.1-9.5
Male	CXP-DM-12	<u>CXP-4MT-12</u>	CXP-NM-12	CXP-MDM-12
Female	CXP-DF-12	CXP-4F-12	CXP-NF-12	CXP-MDF-12
Right Angle	CXP-DRA-12	CXP-4RT-12	CXP-NRA-12	CXP-MRA-12

7/8" Annular Cable

Cables Supported: CommScope AVA5, AVA5RK, AL5, LDF5, VXL5; RFS LCF78, UCF78; NK Draka RFA78; Eupen EC5; Leoni Flexline 7/8"R; LS/Superior Essex LHF 22D, LHF-22DU; Hansen RF5078; Rosenberger SL 7/8".

Installation Instructions

Interface Types	7-16 DIN	4.3-10	N	4.1-9.5
Male	CXP-DM-78	<u>CXP-4MT-78</u>	CXP-NM-78	CXP-MDM-78
Female	CXP-DF-78	CXP-4F-78	CXP-NF-78	n/a

CXP_Connector_Buyers_Guide